



USE APPROPRIATE BASE TIE-IN DETAIL

- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR MOST CURRENT INFORMATION.
 2. APPLY ECOWHITE LAP SEALANT AS SHOWN. REFER TO EW-LS-9 FOR SEAM EDGE TREATMENT.
 3. ECOWHITE 6" QUICKSEAM FLASHING (6" x 6" MIN. WITH ROUNDED CORNERS) MAY BE USED IN LIEU OF ECOWHITE QUICKSEAM T-JOINT COVER. REFER TO EW-LS-9 FOR SEAM EDGE TREATMENT.
 4. REFER TO EW-LS-1 FOR ADDITIONAL LAP SPICE INFORMATION.
 5. USE SINGLE-PLY QUICKPRIME TO CLEAN AND PRIME EPDM MATING SURFACES PRIOR TO INSTALLATION OF QUICKSEAM PRODUCTS.

Firestone
 BUILDING PRODUCTS
 NOBODY COVERS YOU BETTER.™
 www.firestonebpc.com

LAP SPICE AT CURB OR WALL FLASHING USING ECOWHITE QUICKSEAM T-JOINT COVER

Rubbergard **EcoWhite** EPDM

ACCEPTABLE SYSTEMS: ADHERED ONLY

MAXIMUM WARRANTY: **20 YEARS**

ISSUE / REVISION DATE:

6/02/2014

DETAIL NO.

EW-LS-7

NOT TO SCALE