



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR MOST CURRENT INFORMATION.
 2. INSTALL METAL WORK TO FIRESTONE INSTALLATION INSTRUCTIONS.
 3. ECOWHITE LAP SEALANT IS REQUIRED ALONG ENTIRE UPSLOPE EDGE OF ECOWHITE QUICKSEAM FLASHING WHEN ROOF SLOPE IS 1" (25 mm) PER FOOT OR GREATER. REFER TO EW-LS-9 FOR SEAM EDGE TREATMENT.
 4. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES OR 200 LBS PER LINEAR FOOT MINIMUM IN ANY GIVEN DIRECTION.
 5. FLANGE OF METAL MUST BE FULLY SUPPORTED BY WOOD AND TERMINATED AT LEAST 1/2" (13 mm) FROM EDGE OF WOOD.
 6. IF THE FLANGE OF THE METAL GUTTER IS NOT COMPLETELY COVERED WITH ECOWHITE QUICKSEAM FLASHING, THEN AN ADDITIONAL PIECE OF ECOWHITE QUICKSEAM FLASHING SHALL BE INSTALLED AT ALL METAL SPLICES REFER TO EW-RE-18.

Firestone
BUILDING PRODUCTS
NOBODY COVERS YOU BETTER.™
www.firestonebpc.com

ROOF EDGE WITH FIRESTONE UNA-EDGE DE (DRIPEDGE)
Rubbergard EcoWhite EPDM
ACCEPTABLE SYSTEMS: ADHERED ONLY

ISSUE / REVISION
DATE: 6/06/2014
NOT TO SCALE

DETAIL NO.
EW-RE-12a

MAXIMUM WARRANTY: **15 YEARS**