



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR MOST CURRENT INFORMATION.
 2. MAXIMUM 6" (152 mm) LONG FASTENERS (NOTE: WOOD BLOCKING MAY BE SUBSTITUTED FOR INSULATION TO REDUCE FASTENER LENGTH REQUIREMENTS).
 3. REFER TO UT-BT-14 AND UTBT-15 FOR QUICKSEAM RPF STRIP LAYOUT AT CORNERS.
 4. BATTEN STRIP MAY BE USED IN LIEU OF METAL PLATES FOR MAS AND FULL ADHERED SYSTEMS ONLY.
 5. BONDING ADHESIVE REQUIRED BETWEEN MEMBRANE AND INSULATION FOR FULLY ADHERED SYSTEMS.

Firestone
 BUILDING PRODUCTS
 NOBODY COVERS YOU BETTER.™
 www.firestonebpc.com

BASE TIE-IN WITH QUICKSEAM RPF AND 2" METAL PLATES - DECK OBSTRUCTION
 ULTRAPLY™ TPO ACCEPTABLE SYSTEMS: ALL

MAXIMUM WARRANTY: **20 YEARS**
 ISSUE / REVISION DATE: 6/26/2014
 DETAIL NO. **UT-BT-6**
 NOT TO SCALE