



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR MOST CURRENT INFORMATION.
 2. REFER TO DETAIL UT-LS-1 OR UT-LS-2 FOR WELD WIDTH.
 3. REFER TO DETAIL UT-BT-11 FOR ULTRAPLY TPO COATED METAL SPLICE
 4. REFER TO DETAIL UT-C-7 & UT-C-9 FOR CORNER FLASHING APPLICATION.
 5. INSTALL METAL WORK TO SMACNA RECOMMENDATIONS
 6. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES OR PROVIDE 200 LBS PER LINEAR FOOT IN ANY GIVEN DIRECTION.
 7. FLANGE METAL MUST BE FULLY SUPPORTED BY WOOD TERMINATED AT LEAST 1/2" (13 mm) FROM EDGE OF WOOD.
 8. WHEN REINFORCEMENT OF TPO MEMBRANE IS EXPOSED, REFER TO UT-LS-14 FOR CUT EDGE SEALANT APPLICATION.

Firestone
 BUILDING PRODUCTS
 NOBODY COVERS YOU BETTER.™
 www.firestonebpc.com

BASE TIE-IN WITH ULTRAPLY TPO COATED METAL
 ULTRAPLY™ TPO
 ACCEPTABLE SYSTEMS: ALL

ISSUE / REVISION
 DATE: 7/01/2014
 NOT TO SCALE

DETAIL NO.
UT-BT-10

MAXIMUM WARRANTY: **20 YEARS**