



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR MOST CURRENT INFORMATION.
 2. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES OR PROVIDE 200 LBS PER LINEAR FOOT IN ANY GIVEN DIRECTION.
 3. 5" QUICKSEAM FLASHING SHALL EXTEND 2" (51 mm) BEYOND EDGE OF CURB FLASHING.
 4. 9" QUICKSEAM FORMFLASH SHALL BE CENTERED OVER 5" QUICKSEAM FLASHING SO THAT IT EXPANDS 2" (51mm) BEYOND EDGE OF 5" QUICKSEAM FLASHING.
 5. REFER TO CUT UT-C-2 FOR OUTSIDE CORNER APPLICATION.

**BASE TIE-IN AT WELDED WATERTIGHT CURB
 (FLANGES UNDER 2")**

ULTRAPLY™ TPO

ACCEPTABLE SYSTEMS: ALL

MAXIMUM WARRANTY: **15 YEARS**

ISSUE / REVISION
 DATE:

7/01/2014

NOT TO SCALE

DETAIL NO.

UT-BT-12