



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR MOST CURRENT INFORMATION.
 2. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES OR PROVIDE 200 LBS PER LINEAR FOOT IN ANY GIVEN DIRECTION.
 3. 5.5" TPO QUICKSEAM FLASHING SHALL EXTEND 2" (51 mm) BEYOND EDGE OF CURB FLASHING.
 4. 9.5" TPO QUICKSEAM FLASHING SHALL EXTEND 2" (51 mm) BEYOND EDGE OF 5.5" TPO QUICKSEAM FLASHING.
 5. FLANGE METAL MUST BE FULLY SUPPORTED BY WOOD AND TERMINATED AT LEAST 1/4" (6 mm) FROM EDGE OF WOOD.
 6. REFER TO CUT UT-C-2 FOR OUTSIDE CORNER APPLICATION.

Firestone
 BUILDING PRODUCTS
 NOBODY COVERS YOU BETTER.™
 www.firestonebpc.com

BASE TIE-IN AT WELDED WATERTIGHT CURB
 (FLANGES 2"-3")
 ULTRAPLY™ TPO ACCEPTABLE SYSTEMS: ALL

ISSUE / REVISION
 DATE:
 7/01/2014

DETAIL NO.
UT-BT-13

MAXIMUM WARRANTY: **20 YEARS**

NOT TO SCALE