



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR THE MOST CURRENT INFORMATION.
  2. REMOVE ALL EXISTING FLASHING, LEAD, ETC. PIPE SURFACE MUST BE FREE OF ALL RUST, GREASE, INSULATION, ETC.
  3. PIPE MUST BE ANCHORED TO ENSURE STABILITY.
  4. NO WRINKLES OR FOLDS UNDER CLAMPING RING.
  5. BONDING ADHESIVE REQUIRED BETWEEN MEMBRANE AND INSULATION FOR FULLY ADHERED SYSTEMS
  6. FIRESTONE FASTENER AND HD SEAM PLATE REQUIRE FOR MAS ONLY. IF FASTENER CANNOT BE INSTALLED AS ILLUSTRATED, REFER TO DETAILS UT-P-15 & UT-P-16
  7. WHEN REINFORCEMENT OF TPO MEMBRANE IS EXPOSED, REFER TO UT-LS-14 FOR CUT EDGE SEALANT APPLICATION.

**PENETRATION (HOT STACK) WITH ULTRAPLY TPO FLASHING (UNSUPPORTED)**  
 ULTRAPLY<sup>™</sup> TPO ACCEPTABLE SYSTEMS: ALL

ISSUE / REVISION DATE:  
 7/22/2014  
 NOT TO SCALE

DETAIL NO.  
**UT-P-6**

MAXIMUM WARRANTY: **20 YEARS**