



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR MOST CURRENT INFORMATION.
 2. ALLOW 1/4" (6 mm) MAX. SPACE BETWEEN SECTIONS OF DRAIN BAR.
 3. ROUND ALL METAL CORNERS AND PLACE BREAK OF GUTTER STRAP 1/4" (6 mm) BELOW TOP OF WOOD NAILER.
 4. DO NOT PRE-NAIL MEMBRANE TO FACE OF THE WOOD NAILER.
 5. CONSTRUCT AND ANCHOR GUTTER IN ACCORDANCE WITH SMACNA.
 6. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES OR 200 LBS PER LINEAR FOOT MINIMUM IN ANY GIVEN DIRECTION.
 7. ON BALLASTED ROOFS, DRAIN BAR HEIGHT MUST MEET OR EXCEED BALLAST OR PAVEMENT HEIGHT (2" (51 mm) MIN. ABOVE ROOF SURFACE).
 8. FIRESTONE TERMINATION BAR AND STAINLESS FASTENERS MAY BE USED IN LIEU OF FIRESTONE DRAIN BAR FOR MECHANICALLY ATTACHED AND FULLY ADHERED SYSTEMS.

Firestone
 BUILDING PRODUCTS
 NOBODY COVERS YOU BETTER.™
 www.firestonebpc.com

ROOF EDGE GUTTER WITH FIRESTONE DRAIN BAR
 ULTRAPLY™ TPO
 ACCEPTABLE SYSTEMS: ALL

ISSUE / REVISION
 DATE: 6/25/2014

DETAIL NO.
UT-RE-13

MAXIMUM WARRANTY: **20 YEARS**

NOT TO SCALE