



- NOTES:**
1. REFER TO FIRESTONE WEBSITE FOR THE MOST CURRENT INFORMATION.
 2. GP SEALANT IS REQUIRED ALONG ENTIRE UPSLOPE EDGE OF QUICKSEAM FLASHING WHEN ROOF SLOPE IS 1" (25 MM) PER FOOT OR GREATER
 3. ROUND ALL METAL CORNERS AND PLACE BACK OF GUTTER STRAP 1/4" (6 mm) BELOW TOP OF WOOD NAILER.
 4. DO NOT PRE-NAIL MEMBRANE TO THE FACE OF THE WOOD NAILER.
 5. CONSTRUCT AND ANCHOR GUTTER IN ACCORDANCE WITH SMACNA RECOMMENDATIONS.
 6. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES OR 200 LBS PER LINEAR FOOT MINIMUM IN ANY GIVEN DIRECTION.
 7. FLANGE OF METAL GUTTER MUST BE FULLY SUPPORTED BY WOOD AND TERMINATED AT LEAST 1/2" (13mm) FROM EDGE WOOD.
 8. CONTACT FIRESTONE ROOFING SOLUTION FOR BALLASTED ROOF SYSTEMS.
 9. IF THE FLANGE OF THE METAL GUTTER IS NOT COMPLETELY COVERED WITH QUICKSEAM FLASHING, THEN AN ADDITIONAL PIECE OF QUICKSEAM FLASHING SHALL BE INSTALLED AT ALL METAL SPLICES. REFER TO UT-RE-27.

MAXIMUM WARRANTY: 25 YEARS

ISSUE / REVISION
DATE: 6/25/2014

DETAIL NO. **UT-RE-16**

ROOF EDGE GUTTER WITH FLANGE

ULTRAPLY™ TPO

ACCEPTABLE SYSTEMS: ADHERED, MAS