



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR THE MOST CURRENT INFORMATION.
 2. REFER TO DETAIL UT-LS-1 OR UT-LS-2 FOR WELD WIDTH.
 3. ROUND ALL METAL CORNERS AND PLACE BACK OF GUTTER STRAP 1/4" (6 mm) BELOW TOP OF WOOD NAILER.
 4. DO NOT PRE-NAIL MEMBRANE TO THE FACE OF THE WOOD NAILER.
 5. CONSTRUCT AND ANCHOR GUTTER IN ACCORDANCE WITH SMACNA RECOMMENDATIONS.
 6. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES OR 200 LBS PER LINEAR FOOT MINIMUM IN ANY GIVEN DIRECTION.
 7. CONTACT FIRESTONE ROOFING SOLUTION FOR BALLASTED ROOF SYSTEMS.
 8. WHEN REINFORCEMENT OF TPO MEMBRANE IS EXPOSED, REFER TO UT-LS-14 FOR CUT EDGE SEALANT APPLICATION.

MAXIMUM WARRANTY: **20 YEARS**

ISSUE / REVISION
DATE: 6/25/2014
DETAIL NO. **UT-RE-17**

Firestone
BUILDING PRODUCTS
NOBODY COVERS YOU BETTER.™
www.firestonebpc.com

ROOF EDGE GUTTER WITH ULTRAPLY TPO COATED METAL
ULTRAPLY™ TPO
ACCEPTABLE SYSTEMS: ADHERED, MAS

NOT TO SCALE