



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR THE MOST CURRENT INFORMATION.
 2. ALLOW 1/4" (6 MM) MAX. SPACE BETWEEN SECTIONS OF DRAIN BAR.
 3. DO NOT PRE-NAIL MEMBRANE TO THE FACE OF THE WOOD NAILER.
 4. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES OR 200 LBS PER LINEAR FOOT MINIMUM IN ANY GIVEN DIRECTION.
 5. IF METAL COUNTERFLASHING EXCEEDS 4" (102 mm) IN WIDTH, A CONTINUOUS CLEAT MUST BE INSTALLED.
 6. ON BALLASTED ROOFS, DRAIN BAR HEIGHT MUST MEET OR EXCEED BALLAST PAYER HEIGHT (2" (51mm) MIN. ABOVE ROOF SURFACE).
 7. FIRESTONE TERMINATION BAR AND STAINLESS STEEL FASTENERS MAY BE USED IN LIEU OF FIRESTONE DRAIN BAR FOR MECHANICALLY ATTACHED AND FULLY ADHERED SYSTEMS ONLY.