



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR THE MOST CURRENT INFORMATION.
 2. 5" TPO QUICKSEAM MUST EXTEND TO WITHIN 3/8" (10 mm) OF THE DRIP EDGE RISE.
 3. INSTALL METAL WORK TO FIRESTONE INSTALLATION INSTRUCTIONS.
 4. GP SEALANT IS REQUIRED ALONG FLASHING WHEN ROOF SLOPE IS 1" (25 mm) PER FOOT OR GREATER.
 5. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES OR 200 LBS PER LINEAR FOOT MINIMUM IN ANY GIVEN DIRECTION.
 6. FLANGE OF METAL MUST BE FULLY SUPPORTED BY WOOD AND TERMINATED AT LEAST 1/2" (13 mm) FROM EDGE OF WOOD.
 7. MECHANICALLY ATTACHED SYSTEMS MUST USE FASTENER AND PLATE OR QUICKSEAM RPF TIE-IN WITH-IN 12" (305 mm) OF DRIP EDGE.

MAXIMUM WARRANTY: **15 YEARS**

ISSUE / REVISION DATE: **6/25/2014** DETAIL NO. **UT-RE-19B**